



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3478 FLEUR DE LIS URN FOUNTAIN

3497 48" TIVOLI URN POOL FOUNTAIN

Open the bag containing the pump kit **P40001**. In the kit you will find:

1 - 40400 (400 gallon per hour pump)	1 - 1/2" plastic tee
1 - 12" long piece of 1/2" clear tubing	1 - rubber stopper
1 - 25" long piece of 1/2" kink free tubing	1 - restrictor clamp

1. Place pool on a firm and level area where fountain will remain. Place a brick under one side of pool to help you retrieve the pump power cord.
2. Find the pump, 1/2" clear tubing 12" long and the rubber stopper. Attach the piece of 1/2" clear tubing 12" long to the outlet side of pump. Place the pump in the pump house located in the center of pool. Run the plug end of the power cord down the PVC pipe located in the pump house. Retrieve cord from under pool and place in groove in bottom of pool. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary. Remove brick from under pool.
3. To level pool, place the level on the top rim of the pump house in the center of the pool. Level in (2) Two directions left to right and front to back. **Shim if needed.**
4. Find the Urn Base and the Urn Top. On a padded surface lay the Urn Base on its side and the Urn Top on its top. On the bottom of the Urn Base and Urn Top you will see a copper pipe. Clean any excess concrete and or tape from these copper pipes.
5. Look inside the pump house. There you will find the piece of 1/2" clear tubing 12" long that you will connect to the Urn Base. **Cut the 1/2" clear tubing to the proper length.** Place a piece of padding on the pump house. Place Urn Base on the pump house. Have one person tilt and hold the Urn Base and another person connect the 1/2" clear tubing to the copper connection located in the bottom of the Urn Base. Remove padding. Position the Urn Base on the pump house.
6. Find the 1/2" plastic tee, the white restrictor clamp and the piece of 1/2" kink free tubing 25" long. Cut 1 piece of the 1/2" kink free tubing 8" long and attach it to the middle connection of the 1/2" plastic tee. Attach the remainder of the 1/2" kink free tubing about 17" long to an end connection of the 1/2" plastic tee. Slip the white restrictor clamp onto the 1/2" kink free tubing 17" long about 6" from the end of the tubing and close the restrictor 3 clicks. Find the remainder of the 1/2" clear tubing and cut a piece 3" long. Attach the piece of 1/2" clear tubing 3" long to the opposite end connection of the 1/2" plastic tee.
7. Find the Urn Top and attach the 1/2" kink free tubing 17" long to the copper pipe located in the bottom of the Urn Top. Attach the 1/2" clear tubing on the opposite end connection of the 1/2" plastic tee to the copper pipe located in the center of the Urn Base cavity. Wrap the 1/2" kink free tubing 8" long around the floor inside the cavity of the Urn Base. Position the Urn Top onto the Urn Base.
8. Fill pool with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the Urn Top using the restrictor clamp until the desired result is achieved. Find the pump house plug. Place the pump house plug in the square opening in the pump house located in the center of the pool.

3478sup

5/5/07