



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3581 - 42" SPRING RAIN PAGODA FOUNTAIN

3582 - 42" PAGODA MOON FOUNTAIN

Open the bag containing the pump kit **P130CP**. In the kit you will find:

- | | |
|---|--------------------|
| 1 – 40160 (160 gallon per hour pump) | 1 - rubber stopper |
| 1 – 12" long piece of 1/2" clear tubing | 1 – hose clamp |

1. Place the pedestal on a firm and level area where fountain will remain. Place the shell on the pedestal.
2. Find the pump and the rubber stopper. Place the pump in the pump house located in the center of the shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under the pedestal and place in groove in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.
3. Find the piece of 1/2" clear tubing 12" long and the hose clamp. Attach the 1/2" clear tubing to the outlet of the pump with the hose clamp. Adjust the dial type flow control located on the front of the pump to the 5-6 o'clock open position (+).
4. Position the shell on the pedestal and level. To level the shell, place the level on the top of the outside rim of the shell. Level in (2) Two directions left to right and front to back. **Shim if needed.**
5. Find the pagoda center. Feed the 1/2" clear tubing through the pagoda center and position it on the top of the pump house. Trim the 1/2" clear tubing 1" above the top surface of the pagoda center.
6. Find the pagoda top. In the bottom of the pagoda top there is a copper pipe. Clean any tape and or dirt from this copper pipe. Attach the 1/2" clear tubing onto the copper pipe and position the pagoda top onto the pagoda center. Find the pagoda finial and position it on the pagoda top.
7. Find the drain plug and insert snugly into the drain insert located in the fountain shell. Remove any tape and or dirt from the drain insert before you insert the drain plug.
8. Fill the shell with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the pagoda top using the dial type flow control located on the front of the pump until the desired result is achieved.

3581sup

10/16/10