



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3694 30" TRANQUILLITY SPILL FOUNTAIN

3699 34" TRANQUILLITY SPILL FOUNTAIN WITH BIRDS

Open the bag containing the pump kit **P16016**. In the kit you will find:

1 – 40160 (160 gallon per hour pump)	1 - rubber stopper	1 – tube of silicone
1 – 6" long piece of 1/2" kink free tubing	1 - 3/4" X 1/2" ADAPTER	1 – hose clamp
1 – 5" long piece of 3/4" clear tubing		

1. Place the pedestal on a firm and level area where fountain will remain. Place the largest shell on the pedestal.
2. Find the pump and the rubber stopper. Place the pump in the pump house located in the center of the shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under the pedestal and place in groove in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.
3. Find the piece of 1/2" kink free tubing 6" long, the piece of 3/4" clear tubing 5" long, the 3/4" X 1/2" ADAPTER and the hose clamp. Attach the 1/2" kink free tubing to the 1/2" side of the 3/4" X 1/2" ADAPTER. Attach the 3/4" clear tubing to the 3/4" side of the 3/4" X 1/2" ADAPTER. Attach the opposite end 1/2" kink free tubing to the outlet of the pump with the hose clamp. Adjust the dial type flow control located on the front of the pump to the full open position (+).
4. Position the largest shell on the pedestal and level. To level the shell, place the level on the top of the outside rim of the shell. Level in (2) Two directions left to right and front to back. **Shim if needed.**
5. Find the second shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell as far as it will go. **Position the pump face down in the pumphouse.** Position this shell on top of the pumphouse of the large shell and level as stated in step #4.
6. Fountain #**3699 34" TRANQUILLITY SPILL FOUNTAIN BIRDS** includes the bird finial. Position the bird finial around the center housing of the second shell.
7. Find the drain plugs and insert them snugly into the drain insert located in the large fountain shell. Remove any tape and or dirt from the drain insert before you insert the drain plug.
8. Fill each shell with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the top shell using the dial type flow control located on the front of the pump until the desired result is achieved.

3694sup

10/16/10