

SET UP INSTRUCTIONS

3713 47" AZUSA URN WALL FOUNTAIN

(YOU WILL NEED HELP WITH THIS FOUNTAIN)

Open the bag containing the pump kit **P22509**. In the kit you will find:

1 – 40225 (225 gallon per hour pump)	1 – 3/4" barb adaptor (npt X barb)	1 – LED light kit
1 - 3/4" kink free tubing 24" long	1 - #3 stopper with hole	
1 – 3/4" female adaptor (slip X fipt)		

1. Find the pump and the 3/4" kink free tubing. Attach one end of the 3/4" kink free tubing to the outlet side of the pump.
2. Place the fountain pool on a firm and level area where the fountain will remain. Place the pump in the pump house located in the rear center of the fountain pool with the tubing facing up. Place the power cord in the groove located in the center of the rear wall of the fountain pool.
3. Find the 3/4" barb adaptor (NPT X BARB) and the 3/4" female adaptor (SLIP X FIPT). Screw the threaded end of the 3/4" barb adaptor (NPT X BARB) into the threaded end of the 3/4" female adaptor (SLIP X FIPT). In the back surface of the fountain wall piece there is a cavity that has two PVC pipes. Remove any tape and excess concrete from both ends of the two PVC pipes. Push the 3/4" female adaptor onto the lower end of the PVC pipe that is in the center of the top cavity until it bottoms out.
4. Place a piece of padding on the pool covering the top surface of the pool. **Carefully** position the fountain wall piece onto the rear of the fountain pool centered over the pump house. Remove the padding. Attach the 3/4" kink free tubing that is connected to the pump onto the 3/4" barb adaptor that is located in the back surface of the fountain wall piece. If necessary, trim the length of the 3/4" kink free tubing.
5. Find the LED light kit. In the kit you will have two connection pieces one 1/2" and one 3/4". Remove the 1/2" connection that is installed in the LED light and install the 3/4" connection. Find the stopper with the hole and slip it onto the power cord of the LED light about 6" from the LED light head. The larger end of the stopper is on the LED light side. Feed the plug end of the LED power cord down the lower PVC pipe located in the top cavity of the urn. Insert the rubber stopper snugly into the lower PVC pipe for a watertight seal. Insert the LED light head into the higher PVC pipe located in the center of the top cavity of the urn.
6. Find the drain plug and insert snugly into the drain insert located in the pool section of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
7. Retrieve the power cords of the pump and the LED light from behind the fountain. Connect the power cord on the LED light to the transformer. Fill the pool section with tap water. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet. Adjust the water flow using the dial type flow control located on the front of the pump.

3713sup

4/2/13