

## SET UP INSTRUCTIONS

### 3762 – CANYON FALLS FOUNTAIN

Open the bag containing the pump kit **P13022**. In the kit you will find:

1 - 40130 (130 gallon per hour pump)	1 – 3/4" female adaptor	1 – hose clamp
1 – 1/2" kink free tubing 6" long	1 – 1/2" barb adaptor	

1. Place the fountain base on a firm and level area where the fountain will remain. Find the drain plug and insert snugly into the drain insert located in the fountain base. Remove any tape and or dirt from the drain insert before you insert the drain plug.
2. Find the pump, the 1/2" kink free tubing and the hose clamp. Attach one end of the 1/2" kink free tubing to the outlet side of the pump with the hose clamp. Find the 3/4" female adaptor and the 1/2" bard adaptor and screw the two pieces together. Attach the barbed end of the 1/2" barb adaptor to the opposite end of the 1/2" kink free tubing. Place the pump with the tubing assembly in the fountain base. Place the power cord of the pump in the groove and over the rear wall of the fountain base.
3. Find the fountain top piece. On a padded surface, **CAREFULLY**, lay the fountain top piece on its side. In the bottom of the fountain top piece there is a PVC pipe. Clean any tape and or dirt from the PVC pipe.
4. **CAREFULLY**, position the fountain top piece on the rear wall of the fountain base. Make sure the power cord of the pump is in the groove. Connect the slip end of the 3/4" female adaptor onto the PVC pipe. Push the adaptor onto the PVC pipe until it bottoms out.
5. Find the pump cover and carefully position it in the fountain base in front of the pump and below the fountain top piece.
6. Fill the fountain bowl with tap water. Plug the pump 110VAC GFCI protected outlet. To adjust water flow to the fountain top piece use the built in dial type flow control located on the front of the pump.