



# MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

## SET UP INSTRUCTIONS

### 3553 – 44" TWO TIER BOCA HEX FOUNTAIN ON HEX POOL

Open bag containing the pump kit **P22514**. In the kit you will find:

- |   |                      |
|---|----------------------|
| 1 - 40225 (225 gallon per hour pump)    | 1 – rubber stopper   |
| 1 - 48" long piece of 3/4" clear tubing | 1 – tube of silicone |

1. Find the pool, the pump and the rubber stopper. Before you set the pool in position, run the power cord of the pump down the PVC pipe located in the center of the pool. Retrieve cord from under the pool. Leave about 12" of slack on the power cord inside the pool. Slip the rubber stopper onto the power cord about 12" from the pump with the smaller end facing away from the pump. Find the tube of silicone. Apply the silicone inside the PVC pipe and around the rubber stopper. Insert the rubber stopper snugly into the PVC pipe. Apply more silicone on top of the rubber stopper and around the power cord. Don't skimp on the silicone you want a watertight seal.
2. Position the pool on a firm and level surface where fountain will remain. Place the power cord of the pump in groove in the bottom of the pool. To level the pool, place the level on the outside rim of the pool. Level in all directions. Shim as needed. Find the pump house and position it in the center of the pool around the pump.
3. Find the 3/4" clear tubing 48" long and the spacer. Connect one end of the 3/4" clear tubing onto the outlet side of the pump. In the center of the spacer there is a hole. Run the piece of 3/4" clear tubing up thru the hole located in the bottom of the spacer. Position the spacer centered on top of the pump house located in the center of the pool.
4. Find the larger shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of the spacer and level in all directions.
5. Find the smaller shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of the larger shell and level in all directions.
6. **Cut the 3/4" clear tubing 4" above the top surface of the center housing on the smaller shell.** Find the finial. Insert the 3/4" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the shell. Position the finial on the fountain.
7. Find the drain plugs and insert them snugly into the drain inserts located in the two larger shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug. Find the pump house plug and position in the opening in the pump house.
8. Fill the pool and both shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.

3553sup 12/19/17