



MASSARELLI'S®
MAKERS OF FINE STONE GARDEN ACCENTS

3743 - 14" Timber Creek Log Fountain

Fountain Information

- Two people are recommended for the installation of this fountain.

Fountain Components

- 3743S - One Piece Shell
- 8759PI - Front Plug
- 8761PL - Back Plug

Pump Kit 99104 Includes

- 40075 - 75 GPH Pump
- 9917 - White LED Underwater Light
- 9958 - 1/2" Kink Free Tubing - 5" Long Piece
- Hose Clamp

Tools Required

- Bubble Level
- Marker or Pen
- Tubing Cutter or Scissors
- Shims (only if leveling is required)



Set Up Instructions

1. Place the one piece shell on a firm and level area where the fountain will be installed.
2. Find the pump, tubing and hose clamp. Attach the tubing to the outlet side of the pump. Secure the tubing with the hose clamp.
3. Place the pump inside of the one piece shell through the opening located on back right hand side of the one piece shell.
4. Slide the other side of the tubing onto the copper pipe located inside the one piece shell on the right hand side.
5. Find the LED Light. Run the LED Light cord out through the back right hand side of the one piece shell. Slide the LED Light onto the copper pipe located in the center of the one piece shell.
6. Find the front plug and place it in the opening on the right hand side of the one piece shell. The plug hides the pump.
7. Find the back plug and place it in the opening on the back right hand side of the one piece shell. The pump cord and LED Light cord should run through the grove of the opening.
8. Fill the one piece shell with water. Stop filling when water is visible.
9. Attach the transformer to the end of the LED light cord. Plug in the LED light and pump to your GFCI outlet. Your fountain will start running.
10. You may need to adjust the water flow. To do so, remove the back plug to access the pump's flow control dial.