

SET UP INSTRUCTIONS 3390 ONE TIER LEAF FOUNTAIN

- 1. Level pedestal on a firm surface where fountain will remain.
- 2. Position shell on pedestal and level. Shim as needed.

3. On a padded surface, place statue of the garden frogs on its back, exposing the bottom. There you will see two copper pipes. Clean any excess concrete from these two copper pipes.

- 4. Open the bag containing the pump kit **P130H**. In the kit you will find:
 - 1 40160 (160 gallon pump)
 - 1 3/8" clear tubing 5" long
 - 1 3/8" kink free tubing 9" long
 - 1 3/8" plastic tee
 - 1 3/8" plastic ell
 - 1 hose clamp

5. Find piece of 3/8" clear tubing that is 5" long and cut two pieces of this tubing 2 1/2" long. Find piece of 3/8" kink free tubing that is 9" long and cut one piece of this tubing 3" long and one piece 6" long.

6. Find the 3/8" plastic tee and the 3/8" plastic ell. On the middle connection of the tee, slip on the piece of 3/8" kink free tubing 6" long. On the opposite end of the 3/8" kink free tubing 6" long slip on one end of the 3/8" plastic ell. On one end connection of the tee, slip on the piece of 3/8" kink free tubing 3" long. On the opposite end connection of the tee, slip on a piece of 3/8" clear tubing 2 1/2" long. On the opposite end of the ell, slip on a piece of 3/8" clear tubing 2 1/2" long.

7. Find the pump and the hose clamp. Attach the opposite end of the 3/8" kink free tubing 3" long to the outlet of the pump with hose clamp. Adjust flow control dial on front of the pump to about the 4 o'clock position.

8. On the 3/8" plastic ell, slip the end with the 3/8" clear tubing 2 1/2" long onto the copper pipe connection to the **LOWER FROG.** On the 3/8" plastic tee and slip the end connection with the 3/8" clear tubing 2 1/2" long onto the copper pipe connection to the **HIGHER FROG**. Push clear tubing on as far as it will go.

9. Lift statue also holding the pump and place the pump in the pump house in the rear of the shell. Run the power cord of the pump out groove at the back of shell. Adjust the position of the statue so that the water will flow into shell. Trim tubing if necessary so statue will sit properly.

10. Fill shell with water and plug pump into 110VAC GFCI protected outlet. Adjust water flow using flow control dial located on front of the pump until the desired result is achieved.

3390sup 4/4/13