



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3672 49" TRANQUILLITY FOUNTAIN

3682 49" TRANQUILLITY SPILL FOUNTAIN

3692 39" TRANQUILLITY FOUNTAIN W/ BIRDS

3698 53" TRANQUILLITY SPILL FOUNTAIN W/ BIRDS

Open the bag containing the pump kit **P40009**. In the kit you will find:

1 -40400 (400 gallon per hour pump)

1 - 27" long piece of 3/4" clear tubing

1 - rubber stopper

1 - 4 " long piece of 1" clear tubing

1. Place the pedestal on a firm and level area where fountain will remain. Place the largest shell on the pedestal.
2. Find the pump, the 3/4" clear tubing 27" long, and the rubber stopper. Place the pump in the pump house located in the center of the shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under the pedestal and place in groove in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary. Attach the piece of 3/4" clear tubing 27" long to the outlet side of pump.
3. Position the largest shell on the pedestal and level. To level the shell, place the level on the top of the outside rim of the shell. Level in (2) Two directions left to right and front to back. **Shim if needed.**
4. Find the second shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the pumphouse of the large shell and level as stated in step #3.
5. Find the third shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the center housing of the second shell and level as stated in step #3.
6. Before you trim the 3/4" clear tubing to length. Push the 3/4" clear tubing back down until the pump is resting on the bottom of the pumphouse. Cut the 3/4" clear tubing 5" above the top surface of the center housing of the third shell.
7. Find the fourth shell and clean the PVC pipe that is in the center of the shell. Run the 3/4" clear tubing up thru the PVC pipe in the center housing of the shell. Position this shell on top of the center housing of the third shell and level as stated in step #3
8. Fountains **#3692 39" TRANQUILLITY FOUNTAIN W/ BIRDS** and **#3698 53" TRANQUILLITY SPILL FOUNTAIN W/ BIRDS** include the bird finial. Position the bird finial around the center housing of the fourth shell.
9. Find the drain plugs and insert them snugly into the drain insert located in the three larger fountain shells. Remove any tape and or dirt from the drain insert before you insert the drain plug.
10. Fill each shell with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the top shell using the dial type flow control located on the front of the pump until the desired result is achieved.

3672sup

6/30/09