

SET UP INSTRUCTIONS

3761 – 40” LOG FOUNTAIN

Open the bag containing the pump kit **P22511**. In the kit you will find:

1 - 40225 (225 gallon per hour pump)	1 – LED light kit (white)	1 – 3 way connector
1 – 3/4" kink free tubing 10" long	1 – no transformer LED light (white)	1 – plastic plug (end cap)
1 – 3/4" barb adaptor		

1. Place the fountain base on a firm and level area where the fountain will remain. Inside the fountain base there is a drain plug. Position the fountain base so that the drain plug is on your left hand side. Remove the rubber drain plug and clean any tape and or dirt from the drain insert. Insert the drain plug snugly into the drain insert.
2. Find the pump and the 3/4" kink free tubing. Attach one end of the 3/4" kink free tubing to the outlet side of the pump. Place the pump with the tubing assembly in the right hand side of the fountain base. Place the power cord of the pump in the groove and over the rear wall of the fountain base.
3. Find the LED lights. Remove the 1/2" barbed connection from both LED lights. Inside the fountain base there two copper pipes. These two copper pipes are the locations for the LED light. Place one LED light on each copper pipe. Place the two power cords of the LED lights in the groove and over the rear wall of the fountain base.
4. Find the fountain top piece and the 3/4" barb adaptor. On a padded surface, **CAREFULLY**, lay the fountain top piece on its side. In the bottom of the fountain top piece there is a threaded PVC insert. Clean any tape and or dirt from the threaded PVC insert. Screw the threaded end of the 3/4" barb adaptor into the threaded PVC insert, hand tight.
5. **CAREFULLY**, position the fountain top piece on the right rear wall of the fountain base. Make sure the power cords of the pump and the LED lights are in the groove. Attach the opposite end of the 3/4" kink free tubing that is connected to the pump to the barbed end of the 3/4" barb adaptor located in the bottom of the fountain top piece.
6. Find the pump cover and carefully position it in the fountain base in front of the pump and below the fountain top piece. Find the top plug and place it onto the fountain top piece covering the water outlet hole.
7. Find the 3 way connector and the plastic plug. Connect the two power cords of the LED lights to the 3 way connector. The third connection on the 3 way connector will be capped off with the plastic plug. Connect the 3 way connector to the transformer.
8. Fill the fountain bowl with tap water. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet. To adjust water flow to the fountain top piece use the built in dial type flow control located on the front of the pump.