

SET UP INSTRUCTIONS 3792 - ECATEPEC URN FOUNTAIN 3793 - 31" TAOS URN FOUNTAIN

Open the bag containing the pump kit **P16022**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)

1 - 2-hole rubber stopper 1 - hose clamp 1 – 1/2" clear tubing 2" long 1 – #3 stopper with .140 hole 1 – tube of silicone

1 – LED light kit (white) 1 – 1/2" kink free tubing 8" long

1. Find the fountain pool, the urn, the pump and the LED light kit. Place the fountain pool on a firm and level area where the fountain will remain. On a padded surface CAREFULLY lay the urn on its side near the fountain pool. The base of the urn will face the fountain pool. Inside the top cavity of the urn there is a PVC insert. Run the plug end and the quick thread nut on the LED light power cord down the PVC insert and out the bottom of the urn.

Find the smaller rubber stopper with the single hole and slip it onto the power cord of the LED light about 12" from the LED light head. CAREFULLY pull the remainder of the LED light power cord out the bottom of the urn. Insert the smaller rubber stopper snugly into the PVC insert.

Find the piece of 1/2" clear tubing 2" long and slip it onto to the 1/2" connection on the LED light head. Connect the opposite end of the 1/2" clear tubing to the copper pipe located in the top cavity of the urn.

- 2. Find the 1/2" kink free tubing 8" long and the hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp.
- 3. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 8" from the body of the pump and on the LED power cord about 18" from the bottom of the urn.
- 4. In the center of the fountain pool there is a PVC insert. Run the plug end of power cords, of the pump and the LED light, down the PVC insert and out the bottom of the fountain pool. Retrieve the power cords from under the fountain pool and place in the groove in the bottom of the fountain pool.

Find the tube of silicone. For a watertight seal apply silicone around the top inside edge of the PVC insert and around the outside edge of the rubber stopper. Insert the 2-hole rubber stopper snugly into the PVC insert. Apply more silicone on top and around the rubber stopper and the power cords. Don't skimp on the silicone you want a watertight seal.

- 5. Place the pump in the pump house. Find the drain plug and insert snugly into the drain insert located in the fountain pool. Remove any tape and or dirt from the drain insert before you insert the drain plug.
- 6. Place the urn on the pump house located in the center of the fountain pool. Be very careful not to stretch the LED light power cord. Reach inside the opening in the pump house and connect the opposite end of the 1/2" kink free tubing to the copper pipe located in the bottom of the urn. Position the urn on the fountain and level. To level, place level on the top rim of the urn and level in all directions. Fill the top cavity of the urn and the fountain pool with tap water.
- 7. Connect the power cord on the LED light to the transformer. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet. Adjust the water flow using the built in flow control dial on the front of the pump. Place the pump house plug in the pump house opening.

3792sup 2/5/15