



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3894 FOUNTAINETTE – TIKI

3897 FOUNTAINETTE – EASTER ISLAND HEAD

Open the bag containing the pump kit **P13012**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)	1 – 2-hole rubber stopper	1 - hose clamp
1 - 3 7/8" long piece of 1/2" clear tubing	1 – 1" X 1/2" adapter	1 – LED light kit (yellow)

1. Find the fountain base, the pump and the LED light kit. On a padded surface **CAREFULLY** lay the fountain base on its side. Inside the fountain bowl there is a PVC pipe. Run the plug end of both power cords, the pump and the LED light, down the PVC pipe and out the bottom of the fountain base leaving about 12" of both wires inside the fountain bowl. Stand the fountain base upright. Retrieve both power cords from under the fountain base and place both in the groove in the bottom of the fountain base. Place the fountain base on a firm and level area where the fountain will remain.

2. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 12" from the body of the pump and about 12" from the LED light. Insert the 2-hole rubber stopper snugly into the PVC pipe.

3. Find the 1" X 1/2" adapter, the piece of 1/2" clear tubing 3 7/8" long and hose clamp. Attach the piece of 1/2" clear tubing to the 1/2" side of the 1" X 1/2" adapter. Attach the opposite end of the 1/2" clear tubing to the outlet side of the pump with the hose clamp. Adjust the dial type flow control located on the front of the pump to the full open position (+).

4. Place the pump in the center of the bowl with the tubing assembly facing up. Insert the LED light head into the 1" side of the 1" X 1/2" adapter. **Add 6" of water in the fountain bowl.**

5. Find the pump cover. In the center of the pump cover there is a PVC pipe. Remove any excess concrete or tape from both ends of this PVC pipe. Place the pump cover onto the bowl **CAREFULLY** guiding the LED light head up through the center hole. Position the pump cover in the center of bowl.

6. Connect the power cord on the LED light to the transformer. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet. Adjust the water flow using the built in flow control dial on the front of the pump.

3894sup

4/15/10