



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3798 – 50" GARDEN SUNBURST FOUNTAIN
3799 – 57" GARDEN HEART FOUNTAIN
3817 – 61" GARDEN DROPLET FOUNTAIN
3833 – 53" GARDEN PETAL POINT FOUNTAIN
3832 – 51" GARDEN STAR FOUNTAIN
3834 – 52" GARDEN ETERNAL LOOP FOUNTAIN
3824 – 53" GARDEN ROCKET SHIP FOUNTAIN
3829 – 52" GARDEN ASTRONAUT FOUNTAIN

Open the bag containing the pump kit **99015**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)	1 – 2-hole rubber stopper	1 - hose clamp
1 – 1/2" clear tubing 15 1/2" long	1 – LED light kit (white)	1 – tube of silicone

1. Place the pedestal on a firm and level surface where the fountain will remain. Place the fountain bowl on the pedestal.
2. Located inside the fountain bowl there is a PVC insert. Remove any tape and or dirt from inside the PVC insert before you insert the rubber stopper. Find the pump and the LED light and run the plug end on both power cords down the PVC insert located in the fountain bowl and down the hole in the pedestal. Leave about 12" of slack on both power cords inside the fountain bowl.
3. Find the 2-hole rubber stopper and the tube of silicone. Apply a dab of silicone in both holes in the rubber stopper. Slip the rubber stopper onto the power cords about 10" from the body of the pump and about 18" from the LED light head with the smaller end of the rubber stopper facing away from the pump and the LED light. Apply silicone around the inside edge of the PVC insert located in the fountain bowl and around the outside edge of the rubber stopper. Retrieve both power cords from under the pedestal and place both in the opening in the bottom of the pedestal. Insert the rubber stopper snugly into the PVC insert. Apply more silicone on top and around the rubber stopper and the power cords. **Don't skimp on the silicone you want a watertight seal.**
4. Find the piece of 1/2" clear tubing 15 1/2" long. Depending on which fountain you purchased you will need to trim the 1/2" clear tubing to the proper length. **See below.**

3798 – 50" GARDEN SUNBURST FOUNTAIN, Trim the 1/2" clear tubing 13 1/2" long
3799 – 57" GARDEN HEART FOUNTAIN, Trim the 1/2" clear tubing 13 1/4" long
3817 – 61" GARDEN DROPLET FOUNTAIN, Trim the 1/2" clear tubing 12 1/2" long
3833 – 53" GARDEN PETAL POINT FOUNTAIN, Trim the 1/2" clear tubing 9 3/4" long
3832 – 51" GARDEN STAR FOUNTAIN, Trim the 1/2" clear tubing 8 1/2" long
3834 – 52" GARDEN ETERNAL LOOP FOUNTAIN, Trim the 1/2" clear tubing 9 1/4" long
3824 – 53" GARDEN ROCKET SHIP FOUNTAIN, Trim the 1/2" clear tubing 12 3/4" long
3829 – 52" GARDEN ASTRONAUT FOUNTAIN, Trim the 1/2" clear tubing 12 1/4" long

5. Attach one end of the 1/2" clear tubing to the outlet of the pump with the hose clamp. Attach the opposite end of the 1/2" clear tubing to the 1/2" barb fitting on the LED light. Adjust the dial type flow control located on the front of the pump to the 3 to 4 o'clock position.
6. Find the drain plug located in the fountain bowl and insert snugly into the drain insert. Clean the hole before you insert the drain plug. Find the pump house plug and place it in the pump house opening.
7. Find the finial and Carefully place it on the pump house located in the center of the fountain bowl while feeding the LED light up through the hole in the center of the finial.
8. Fill the fountain bowl with tap water. Connect the power cord on the LED light to the transformer. Plug the power cord of the pump and the LED light transformer into a 110VAC GFCI protected outlet. If necessary, adjust the water flow using the dial type flow control located on the front of the pump. Find the pedestal plug and place it in the pedestal opening.