SET UP INSTRUCTIONS 3859 – FOUNTAINETTE - TUSCAN URN 3864 – TUSCAN HEX URN FOUNTAIN

Open the bag containing the pump kit 99103. In the kit you will find:

1 - 40160 (160 gallon per hour pump) 1 - 2-hole rubber stopper

1-2" long piece of 1/2" clear tubing 1-#3 stopper with hole 1-LED light kit (white)

1 – 8" long piece of 1/2" clear tubing

1. Find the fountain bowl, the urn top, the pump and the LED light kit. On a padded surface **CAREFULLY** lay the fountain bowl and the urn top in line on their side. Inside the cavity of the urn top there is a PVC insert. Run the plug end and the quick thread nut on the LED light power cord down the PVC insert and out the bottom of the urn. Pull the remainder of the LED light power cord out the bottom of the urn top.

Find the smaller stopper with the single hole and slip it onto the power cord of the LED light about 13" from the LED light head. Insert the smaller rubber stopper snugly into the PVC insert.

Find the piece of 1/2" clear tubing 2" long and connect it to the 1/2" connection on the LED light head. Connect the opposite end of the 1/2" clear tubing to the copper pipe located in the cavity of the urn top.

- 2. Find the 1/2" kink free tubing 8" long and the hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp.
- 3. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 8" from the body of the pump and on the LED power cord about 8" from the bottom of the urn top.
- 4. Inside the fountain bowl there is a PVC pipe. Run the plug end of both power cords, the pump and the LED light, down the PVC pipe and out the bottom of the fountain bowl. Insert the 2-hole rubber stopper snugly into the PVC pipe. Stand the fountain bowl upright. **Be very careful not to stretch the LED light power cord.** Place a piece of padding on the top of the fountain bowl. Place the urn top on the padding that is on the fountain bowl. Retrieve both power cords from under the fountain base and place both in the groove in the bottom of the fountain bowl. Place the fountain bowl on a firm and level area where the fountain will remain.
- 5. Connect the opposite end of the 1/2" kink free tubing to the copper pipe located in the bottom of the urn top. Position the urn top on the fountain and level. To level, place level on the top rim of the urn top. Level in two directions front to back and left to right. Add 4" of water in the fountain bowl and fill the top shell.
- 6. Connect the power cord on the LED light to the transformer. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet. Adjust the water flow using the built-in flow control dial on the front of the pump.