

SET UP INSTRUCTIONS

3673 79" CLASSIC FOUR TIER FOUNTAIN ON 6' POOL

Open bag containing the pump kit **P70001**. In the kit you will find:

1 - 02527 (700 gallon per hour pump) 1 – hose clamp 1 – tube of silicone 1 – rubber stopper
1 - 84" long piece of 3/4" clear tubing 1 - 5" long piece of 1" clear tubing

1. Prepare a level base of 4" poured concrete or 6" compacted crushed limestone. The 6' fountain pool has an outside base diameter of 77".
2. In the center of the 6' fountain pool you will see a PVC insert. Find the pump and run the plug end of the power cord down the PVC pipe. Leave three feet of slack on the power cord from the pump to the PVC pipe. Retrieve the power cord from under the pool and place the power cord in the groove in the bottom of pool. Find the rubber stopper and slip it onto the power cord with the smaller end facing away from the pump. Find the tube of silicone and apply around the outside edge of the rubber stopper and around the power cord. Insert the rubber stopper snugly into the PVC pipe.
3. Place the 6' fountain pool in the center of the area where the fountain is to be displayed.
4. Find the round pumphouse and position it in the center of the 6' fountain pool and level. To level, place level on top rim of the pump house. Level in (2) Two directions left to right and front to back. **Shim as needed.**
5. Find the fountain pedestal and position it on the round pumphouse. Find the 3/4" clear tubing and insert one end into center hole that is in the fountain pedestal down into the pumphouse and out the water inlet hole that is in the pumphouse.
6. Find the largest shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the pedestal and level. To level the shell, place the level on center housing in center of shell. Level as stated in step #4.
7. Find the second shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the large shell and level. To level shell, place the level on center housing in center of shell. Level as stated in step #4.
8. Find the third shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the second shell and level. To level shell, place the level on center housing in center of shell. Level as stated in step #4.
9. Find the fourth shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the third shell and level. To level shell, place the level on center housing in center of shell. Level as stated in step #4.
10. Before you trim the 3/4" clear tubing to length. Push the 3/4" clear tubing back down into the pumphouse. Connect the 3/4" clear tubing to the pump with a hose clamp. Cut the length of the 3/4" clear tubing to 7 1/2" above the top surface of the center housing of the fourth shell.
11. Find the finial. Remove any excess concrete or tape from both ends and inside of the PVC pipe in the finial. Slip the finial onto the 3/4" clear tubing and position the finial on top of fountain.
12. Find the drain plugs and insert them snugly into the drain insert located in the three shells and the fountain pool. Remove any tape and or dirt from the drain insert before you insert the drain plugs.
13. Fill the shells and the pool with water. Plug the pump into a 110VAC GFCI protected outlet. To adjust the water flow to the finial, unplug the pump and remove the finial from the fountain. Trim the 3/4"

clear tubing another 1/2" shorter and reposition the finial on the fountain. If necessary repeat by cutting the 3/4" clear tubing another 1/2" shorter. This will regulate water flow from the finial until the desired result is achieved.