



# MASSARELLI'S®

*MAKERS OF FINE STONE GARDEN ACCENTS*

## SET UP INSTRUCTIONS

### 3820 TWO TIER LANE FOUNTAIN

Open bag containing the pump kit **P130EP**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)	1 - rubber stopper	1 - tube of silicone
1 - 30" long piece of 1/2" clear tubing	1 - hose clamp	

1. Place pedestal on a firm level surface where fountain will remain. Place the largest shell on the pedestal.
2. Find the pump, 1/2" clear tubing 30" long and the rubber stopper. Place pump in pump house in center of shell and run the plug end of the electrical cord down the PVC pipe located in the pump house and down into the pedestal. Retrieve cord from under pedestal and place in groove in the bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust position of the rubber stopper on the power cord if necessary. Attach one end of 1/2" clear tubing outlet side of the pump with the hose clamp.
3. Position the largest shell on pedestal and level. To level shell, place level on top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**
4. Find the second shell and run the 1/2" clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the large shell and level. To level shell, place level on center housing in center of shell. Level as stated in step #3.
5. Find the finial. In the center of the finial you will see a copper pipe. Remove any excess concrete or tape from both of the copper pipe. Trim the 1/2" clear tubing to the proper length and attach to the copper pipe in the bottom of the finial. Position the finial on the fountain. Find the drain plug and insert snugly into the drain insert located in the larger shell. Remove any tape and or dirt from inside the drain insert before you insert the drain plug
6. Fill shells with water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.

**3408sup 4/22/11**