



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3769 - TWO TIER OVAL JUBILEE FOUNTAIN

Open bag containing the pump kit **P130DP**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)	1 – rubber stopper	1 – hose clamp
1 - 18" long piece of 1/2" clear tubing	1 – tube of silicone	

1. Place pedestal on a firm and level surface where fountain will remain. Place the larger shell on the pedestal.
2. Find the pump, 1/2" clear tubing 18" long, the hose clamp, the rubber stopper and the tube of silicone. Place pump in pump house in center of shell and run the plug end of the electrical cord down the PVC insert located in the center of the pump house and down into the pedestal. Retrieve cord from under pedestal and place in groove in the bottom of Pedestal. Apply a dab of silicone into the hole in the rubber stopper. Slip the rubber stopper onto the power cord about 7" from the body of the pump with the smaller end facing away from the pump. Apply silicone around the inside the top edge of the PVC insert and around the outside of the rubber stopper. Insert the rubber stopper snugly into the PVC insert. Apply more silicone around and on top of the rubber stopper. You want to make a water tight seal so don't skimp on the silicone. Attach one end of 1/2" clear tubing to the outlet side of the pump with the hose clamp.
3. Position the larger shell on pedestal and level in all directions. **Shim as needed.**
4. Cut the 1/2" clear tubing 14" above the top surface of the pump house on the larger shell
5. Find the top shell. Insert the 1/2" clear tubing into the PVC pipe in the bottom of the top shell and slide the top shell down onto the pump house of the larger shell. Position the top shell on the fountain and level in all directions.
6. Find the drain plug and insert snugly into the drain inserts located in the larger shell. Remove any tape and or dirt from the drain insert before you insert the drain plug. Fill both shells with tap water and plug pump into a 110VAC GFCI protected outlet.
7. To adjust the water flow use the dial type flow control located on the front of the pump. This will regulate water flow from the finial until the desired result is achieved.

3769sup **3/26/14**