

SET UP INSTRUCTIONS

- 3504 30" CONTEMPORARY DIAG FOUNTAIN - RIGHT
- 3506 30" CONTEMPORARY DIAG FOUNTAIN - LEFT
- 3507 42" CONTEMPORARY DIAG FOUNTAIN - LEFT
- 3508 42" CONTEMPORARY DIAG FOUNTAIN - RIGHT
- 3509 34" CONTEMPORARY SWIRL FOUNTAIN
- 3511 45" CONTEMPORARY SWIRL FOUNTAIN
- 3512 56" CONTEMPORARY CURVE FOUNTAIN
- 3513 56" CONTEMPORARY VASE FOUNTAIN
- 3597 35" BIRDS OF A FEATHER FOUNTAIN

Open bag containing the pump kit **P7503**. In the kit you will find:

- | | |
|--|--------------------|
| 1 - 40075 (75 gallon per hour pump) | 1 - hose clamp |
| 1 - 8" long piece of 1/2" clear tubing | 1 - rubber stopper |
| 1 - 1" long piece of 3/8" clear tubing | |

1. Place the pedestal on a firm and level surface where fountain will remain. To level pedestal, place level on the top of the pedestal. Level in (2) Two directions left to right and front to back. **Shim as needed.**

2. Find the pump, the piece of 3/8" clear tubing 1" long, the piece of 1/2" clear tubing 8" long, rubber stopper and hose clamp. Slip the piece of 3/8" clear tubing 1" long onto the outlet side of the pump and then attach one end of the 1/2" clear tubing 8" long to the outlet side of the pump with a hose clamp. Place pump in the pump house in center of pedestal and run the plug end of the electrical cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under pedestal and place in the groove in the bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.

For fountain #3597 35" BIRDS OF A FEATHER FOUNTAIN only.

1a. Place the pedestal on a firm level surface where fountain will remain. Place the shell on the pedestal.

2a. Find the pump, the piece of 3/8" clear tubing 1" long, the piece of 1/2" clear tubing 8" long, rubber stopper and hose clamp. Slip the piece of 3/8" clear tubing 1" long onto the outlet side of the pump and then attach one end of the 1/2" clear tubing 8" long to the outlet side of the pump with a hose clamp. Place pump in the pump house in center of the shell and run the plug end of the electrical cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under pedestal and place in the groove in the bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary. Position the shell on the pedestal and level. To level shell, place level on the top rim of the pump house located in the center of the shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**

3. Adjust pump. The pump has a built in flow control dial located on the front of the pump. **Set the flow control dial to the full open position.**

4. Find the finial. On a padded surface lay the finial on its side. You will see a copper pipe in the base of the finial. Remove any excess concrete or tape from both ends of this copper pipe.

5. Trim the 1/2" clear tubing connected to the pump to the proper length. Attach the piece of 1/2" clear

tubing to the copper pipe located in the base of the sphere. Place the finial on top of pedestal.

6. Fill with water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the built in flow control dial on the front of the pump.