

SET UP INSTRUCTIONS

3596 78" BELLA THREE TIER FOUNTAIN

Open bag containing the pump kit **P51501**. In the kit you will find:

1 – 02617 (515 gallon per hour pump)	1 – 3/4" X 1/2" plastic tee	1 - rubber stopper
1 - 5" long piece of 1" clear tubing	1 - 1/2" plastic ell	
1 - 54" long piece of 3/4" clear tubing		
1 - 5" long piece of 1/2" clear tubing		

1. Place pedestal on a firm and level surface where fountain will remain. Place a brick under one side of pedestal. This will help you retrieve the power cord from under the pedestal. Place the largest shell on the pedestal.
2. Find the pump, 3/4" clear tubing 54" long and the rubber stopper. Attach one end of the 3/4" clear tubing 54" long onto the outlet side of the pump. Place pump in the pump house in the center of the shell and run the plug end of the electrical cord down the PVC pipe in the pump house and down through the pedestal. Retrieve cord from under pedestal and place in access hole in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.
3. Remove brick from under pedestal. Position the largest shell on pedestal and level. To level shell, place level on the top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**
4. Find the larger spacer. Run the 3/4" clear tubing through the center hole in spacer. Place spacer on top of pumphouse in center of shell and level as in step #3.
5. Find the second shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the spacer and level. To level shell, place level on center housing in center of shell. Level as stated in step #3. Cut the 3/4" clear tubing 1½" below the top surface of the center housing of second shell. Find 3/4" X 1/2" plastic tee and attach an end connection of the tee to the end of the 3/4" clear tubing.
6. Find the 1/2" clear tubing 5" long and attach an end to the middle connection of the 3/4" X 1/2" plastic tee and place tubing in the groove located in the wall of the center housing of the second shell. Cut the 1/2" clear tubing about 1" past the outside wall. Find the 1/2" plastic ell and attach it to the 1/2" clear tubing just outside the wall pointing down. Find the remainder of the 3/4" clear tubing and attach it to the opposite end connection of the 3/4" X 1/2" plastic tee located in the center housing of the second shell.
7. Find the smaller spacer. Run the 3/4" clear tubing through the center hole in spacer. Place spacer on top of center housing in center of shell and level as in step #3.
8. Find the third shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the spacer and level. To level shell, place level on center housing in center of shell. Level as in step #3.
9. Cut the 3/4" clear tubing 10" above the center housing of the third shell. Find the piece of 1" clear tubing 5" long and slip it onto the end of the 3/4" clear tubing all the way until both ends are even.
10. Find the finial. On the bottom of the finial you will see a PVC pipe. Clean any excess concrete or tape from both ends and inside of this PVC pipe. Slip the finial onto the 1" clear tubing and position the finial on the third shell.
11. Find the drain plugs and insert them snugly into the drain insert located in the three shells. Remove any tape and or dirt from the drain inserts before you insert the drain plugs. Fill shells with water and plug pump into a 110VAC GFCI protected outlet.
12. You will do the **final adjustment** after your fountain is completely set up and the water is running. There are eight copper pipes located in each of the two top shells. These sixteen copper pipes are where the water will drip from shell to shell. Using a phillips head screw driver, insert the round tip on the screw driver about 1" into the copper pipes that are on the bottom side of the shell and **carefully bend** each copper pipe so the water will fall straight down into the shell below.