



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3651 47" EMILIA COLUMN FOUNTAIN

Open bag containing the pump kit **P22503**. In the kit you will find:

1 - 40225 (225 gallon per hour pump) 1 - rubber stopper
1 - 27" long piece of 3/4" clear tubing 1 - tube of silicone

1. Place the pedestal on a firm and level surface where fountain will remain. Place the shell on the pedestal.
2. Find the pump, the 3/4" clear tubing 27" long and the rubber stopper. Attach the piece of 3/4" clear tubing 27" long onto the outlet side of the pump. Place the pump in the pump house located in the center of the shell and run the plug end of the electrical cord down the PVC pipe in the pump house and down through the pedestal. Retrieve cord from under the pedestal and place in groove in the bottom of the pedestal. Leave enough slack in the power cord so the pump will rest on the bottom of the pumphouse. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary. Position the pump with the dial flow control facing the water inlet hole in the pumphouse wall.
3. Position the shell on the pedestal and level. To level the shell, place the level on the pumphouse located in the center of the shell. Level in (2) Two directions left to right and front to back. Shim as needed.
4. Cut the 3/4" clear tubing at 17 1/2" above the top surface of the pumphouse.
5. Find the column finial and place it on a padded surface. Clean both end of the PVC pipe that runs through the center of the column.
6. Place padding on the pumphouse to protect it from getting scratched. Carefully place the column finial on the pumphouse running the piece of 3/4" clear tubing up thru the PVC pipe located in the center of the column. Position the column finial centered on top of the pumphouse located in the center of the shell.
7. Find the drain plug and insert snugly into the drain insert located in the shell of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug. Fill shell with tap water and plug the pump into a 110VAC GFCI protected outlet. To adjust the water flow to the finial use the dial type flow control located on the front of the pump until the desired result is achieved.

3651sup 6/2/10