



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3662 GARDEN GLOW FOUNTAIN

Open the bag containing the pump kit **P16012**. In the kit you will find:

1 - 40160 (160 gallon per hour pump)	1 - 1/2" plastic tee	1 - hose clamp
1 - 2" long piece of 1/2" clear tubing	1 - rubber stopper	
1 - 12" long piece of 1/2" kink free tubing	1 - metal restrictor	

1. Place the pedestal on a firm and level area where the fountain will remain. Place the shell on the pedestal.
2. Find the 1/2" plastic tee and the piece of 1/2" clear tubing 2" long. Attach the piece of 1/2" clear tubing to the middle connection of the 1/2" plastic tee. Find the piece of 1/2" kink free tubing 12" long and cut two 6" long pieces. Attach a piece of 1/2" kink free tubing 6" long onto the two end connection of the 1/2" plastic tee. Find the metal restrictor and slip it onto one of the pieces of 1/2" kink free tubing 6" long about half way. This will be the tubing assembly.
3. Find the pump, tubing assembly, rubber stopper and the hose clamp. Attach the middle connection of the 1/2" plastic tee to the outlet side of pump with hose clamp. **Tighten the metal restrictor onto the 1/2" kink free tubing and then loosen the restrictor four half turns.** Place the pump in the pump house located in the center of shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down thru the pedestal. Retrieve cord from under pedestal and place in groove in bottom of pedestal. Leave enough slack in the power cord so the pump will rest on the bottom of the pumphouse. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.
4. Position shell on pedestal and level. To level shell, place the level on the top rim of the pump house in the center of the shell. Level in (2) Two directions left to right and front to back. **Shim if needed.**
5. Find the finial. On a padded surface **carefully** lay the finial on its side. On the bottom of the finial you will see two copper pipes. Clean any excess concrete and or tape from the two copper pipes.
6. Inside the pump house you will find the two pieces of 1/2" kink free tubing that you will connect to the finial. Place a piece of padding on the pump house. Place the finial on pump house. Have one person tilt and hold the finial and another person **connect the piece of 1/2" kink free tubing with the metal restrictor onto the copper pipe for the lower flame.** Connect the second piece of 1/2" kink free tubing onto the second copper pipe. Remove padding and position the finial on the pump house.
7. Fill shell with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump and the metal restrictor until the desired result is achieved.

3662sup

6/16/08