



3464 - 34" Candia Square Fountain



Set Up Instructions

Fountain Information

 Two people are recommended for the installation of this fountain.

Fountain Components

8775PH - 6" Square Pumphouse

- 8837PH 6" Square Pumphouse Plug
- 346433 Square Base
- 8792PH 11" Pumphouse
- 8792PL 11" Pumphouse Plug
- 346420 Top Shell
 4173 Finial

Pump Kit 99106 Includes

- 40225 225GPH Pump
- 9962 3/4" Clear Tubing 10" Long Piece
- 9940 Rubber Stopper
- 1" PVC Pipe 3" Long Piece

Tools Required

- Bubble Level
- Marker or Pen
- · Tubing Cutter or Scissors
- · Shims (only if leveling is required)
- 1. Find the 6" square pumphouse and place it on a firm and level area where the fountain will be installed. The side with the 6" opening should be the back side of the fountain.
- 2. Find the square base and place in on top of the 6" square pumphouse.
- 3. Find the pump and place it in the center of the square base. Run the plug end of the pump's electrical cord through the center of the base and 6" square pumphouse. Leave 12" of cord slack inside the square base.
- 4. Find the rubber stopper and insert onto the cord by spreading the slit open. The smaller end of the rubber stopper should be facing away from the pump. Insert the rubber stopper snuggly into the PVC pipe located in the center of the base until it is flush.
- 5. Find the 11" pumphouse and place it in the center of the square base. The 11" pumphouse goes over the pump. The side with the 11" opening should be facing the back of the fountain.
- 6. Find the 3/4" clear tubing and attach it to the outlet side of the pump. The tubing should be standing straight up after it is attached.
- 7. Find the top shell and slide it over the tubing. Position the top shell on top of the 11" pumphouse. Level and shim if needed.
- 8. Find the 3" long piece of 1" PVC Pipe and insert it into the PVC fitting located in the center of the top shell.
- 9. Find the finial and place it along side the the tubing. Push down on the tubing to make sure that the pump is positioned on the floor of the square base. The pump should always be sitting flat on floor of the square base.
- 10. Trim the tubing half way up the finial. Slide the finial onto the tubing and position the finial in the center of the top shell.
- 11. Find the 6" pumphouse plug and the 11" pumphouse plug. Place the 6" pumphouse plug in the opening located in the back of the 6" pumphouse. Place the 11" pumphouse plug in the opening located in the back of the 11" pumphouse.
- 12. Fill the base with water. Stop filling when water fills the entire base.
- 13. Plug in the pump to your GFCI outlet. Your fountain will start running.
- 14.You may need to adjust the water flow. To do so use the flow control dial located on the front of the pump.