



**MASSARELLI'S®**  
MAKERS OF FINE STONE GARDEN ACCENTS

## 3670 - 77" Vincenza Fountain with Surround and 6' Fiberglass Pool



### Fountain Information

- Four people are recommended for the installation of this fountain.

### Fountain Components

- 9989 - 6' Fiberglass Pool
- 87516 - 6' Pool Wall Section - Qty of 4
- 8751 - Pool Seam Covers - Qty of 4
- 8780PH - 6" Round Pumphouse
- 8780PL - 6" Round Pumphouse Plug
- 8225P - Pedestal
- 3085S - Bottom Shell
- 8228SP - 12" Spacer
- 3298S - Top Shell
- 4894 - Finial

### Tools Required:

- Screw Driver
- Bubble Level
- Marker or Pen
- Scissors or Tubing Cutters
- Shims (only if leveling is required)

### Pump Kit P70001 Includes:

- 9934 - 700 GPH Pump
- 9962 - 3/4" Clear Tubing - 84" Long Piece
- 9963 - 1" Clear Tubing - 5" Long Piece
- 9940 - Rubber Stopper
- Hose Clamp
- Tube of Silicone

## Set Up Instructions

1. Prepare a level base of 4" poured concrete or 6" compacted crushed limestone. The completed 6' fountain pool has an outside base diameter of 84".
2. Find the 6' fiberglass pool, the pump and the rubber stopper. Slip the rubber stopper onto the power cord about 24" from the pump. Place the pump in the center of the pool and run the plug end of the power cord down through the PVC pipe in the center of the pool. Retrieve the power cord from bottom side of pool. Insert the rubber stopper snugly into the PVC pipe in the center of the pool. Apply silicone on top and around the rubber stopper and power cord. Apply the silicone heavily for a watertight seal.
3. Place the 6' fiberglass pool in the center of the area where the fountain is to be displayed. Retrieve the power cord from bottom side of pool and pull the cord through the back end of the pool towards the power outlet.
4. Find the pump house and carefully position it in the center of the pool. The opening in the pump house should face toward the back of fountain.
5. Find the pedestal and carefully position it on the pump house.
6. Find the largest shell and position it on top of the pedestal. Level in all directions and shim if needed.
7. Find the 3/4" clear tubing and run it through the PVC insert in the center housing of the shell, down through the center hole of the pedestal and then down into the pumphouse and out the water inlet hole in the pumphouse.

8. Find the spacer and run the 3/4" clear tubing up thru the center hole and position the spacer on top of the center housing located in center of largest shell and level in all directions.
9. Find the smaller shell and run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell centered on top of the spacer and level in all directions.
10. Connect the 3/4" clear tubing to the pump with the hose clamp.
11. The 3/4" clear tubing should be sticking out of the top shell. Find the finial and place along side of the tubing. Trim the tubing about half way up the finial.
12. Find the 1" clear tubing and slip it onto the 3/4" clear tubing. The 1" clear tubing is included to allow the water to flow nicely out of the finial. Trim the 1" clear tubing as necessary. The tubing should not be flush with the top of the finial.
13. Find the finial and slip it on to the tubing. Position the finial on top of fountain.
14. Find the four pool wall sections. Position each piece of the wall section around the fiberglass pool, lining up the inside radius of the wall section with the inside radius of the fiberglass pool.
15. Find the 4 pool wall seam covers and place over the pool wall seams.
16. Fill shells with water and plug pump into a 110VAC GFCI protected outlet.