



3838 - 98" Three Tier Savonabella Fountain



Fountain Information

Two people are recommended for the installation of this fountain.

Fountain Components

- 8721SP Pedestal
- 3167S Bottom Shell
- · 3167PL Bottom Shell Plug
- 8832SP Bottom Spacer
- 3166S Middle Shell
- 8833SP Top Spacer
- 3165S Top Shell
 4915 Finial

Pump Kit P46018

- 1 40460 460 GPH Pump
- 1 9962 3/4" Clear Tubing 66" Long Piece
- 1 9940 Rubber Stopper
- 1 10210 Hose Clamp

Tools Required

- Bubble Level
 - · Marker or Pen
- · Tubing Cutter or Scissors
- Set Up Instructions. Shims (only if leveling is required)
- 1. Place the pedestal on a firm and level area where the Fountain will be installed.
- 2. Find the bottom shell and place on top of the pedestal.
- 3. Find the pump, 3/4" clear tubing, and the rubber stopper. Place the pump in the pumphouse in the center of the bottom shell. Run the plug end of the pump's electrical cord down the PVC pipe located in the center of the pumphouse and runs down the center of the pedestal. Retrieve the cord from under the pedestal and run the cord through the groove at the bottom the pedestal.
- 4. Find the rubber stopper and insert onto the cord by spreading the slit open. The smaller end of the rubber stopper should be facing away from the pump. Insert the rubber stopper snuggly into the PVC pipe until it is flush.
- 5. Find the 3/4" clear tubing and attach it on the outlet side of the pump. Secure it using the hose clamp.
- 6. Place a level on the top rim of the pumphouse to level the bottom shell. Level in two directions.Shim if needed
- 7. Find the bottom spacer and run the 3/4" clear tubing through the center hole of the spacer. Position the spacer on top of the pumphouse located in the center of the bottom shell and level. Shim if needed.
- 8. Find the middle shell and run the 3/4" clear tubing through the center housing of the shell. Position the shell on top of the bottom spacer and level. Shim if needed.
- 9. Find the top spacer and run the 3/4" clear tubing through the center of the spacer. Position the top spacer on top of the center housing of the middle shell and level. Shim if needed.
- 10. Find the top shell and run the 3/4" clear tubing through the center housing of the shell. Position the she top shell on top of the top spacer and level. Shim if needed.
- 11. Find the finial and position it on top of the center housing of the top shell. Run the tubing along the side of the finial. Push down on the tubing to make sure that the pump is positioned on the floor of the pumphouse. The pump should always be sitting flat on the floor of the pumphouse.
- 12. Cut the tubing 1/2" shorter than the height of the finial. Slide the tubing through the center of the finial and place the finial on the center housing of the top shell.
- 13. Find the bottom shell plug and place it in the opening of the pumphouse located in the bottom shell.
- 14. Fill the shells with water. Stop filing when water is visible in each shell.
- 15. Plug in the pump to your GFCI outlet. Your fountain will start running.