



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3589 66" LIGHTHOUSE FOUNTAIN

Open bag containing the pump kit **P29003**. In the kit you will find:

- | | |
|---|----------------------|
| 1 - KING-400 (400 gallon per hour pump) | 1 - 1/2" plastic tee |
| 1 - 8" long piece of 1/2" clear tubing | 2 - rubber stopper |

Note: Using a little ingenuity you can add your own light kit (110vac or 12 volt with a transformer rated for outdoor use) to this fountain. Remember the light kit you add will be run up from the pedestal using the same path as the pump power cord which is run down the pedestal. When you run the wire for the light you will end up in the pump house of the fountain. From the pump house to the top of the lighthouse you will need about four feet of wire.

1. Find the piece of 1/2" clear tubing 8" long and cut one piece 2" long. Find the 1/2" plastic tee and attach the piece of 1/2" clear tubing 2" long onto the middle connection. Find the pump and attach the remainder of the 1/2" clear tubing to the outlet side of the pump.
2. Place pedestal the on a firm and level surface where fountain will remain. Place the rock pool on the pedestal.
3. Place pump and attached 1/2" clear tubing into the pump house located in center of the rock pool and run the plug end of the electrical cord down the PVC pipe located in the pump house and down thru the pedestal. Retrieve cord from under pedestal and place in groove in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust position of the rubber stopper on the power cord if necessary.
4. Position the rock pool on the pedestal and level. To level the rock pool, place level on top rim of the pump house in the center of the rock pool. Level in (2) Two directions left to right and front to back. **Shim as needed.** Place a couple pieces of padding on the pump house located in the center of the rock pool.
5. Find the small shell. In the bottom of the small shell there is a copper pipe, remove any excess concrete or tape from both ends of copper pipe. Trim the 1/2" clear tubing that is connected to the pump to the proper length. Place the small shell on the pump house and connect the 1/2" clear tubing to the copper pipe located in the bottom of the small shell. Remove the padding and position this shell on top of the pump house and level. To level shell, place level on center housing in center of shell. Level as stated in step #4.
6. Find the 1/2" plastic tee with the 1/2" clear tubing attached and attach the middle connection to the copper pipe located in the center housing of the small shell.
7. Find the lighthouse base and position on the center housing of the small shell. Find the lighthouse finial and position on top of lighthouse base.
8. Find the drain plug and insert snugly into the drain insert located in the rock pool. Fill rock pool with water and plug pump into a 110VAC GFCI protected outlet.

3589sup

4/23/07