



# MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

## SET UP INSTRUCTIONS

### 3629 57" PETAL POINT FOUNTAIN

Open bag containing the pump kit **P29014**. In the kit you will find:

- 1 - KING 400 (400 gallon per hour pump)
- 1 - rubber stopper
- 1 - 10" long piece of 3/4" clear tubing
- 1 - 6" long piece of 1/2" clear tubing

1. Place the pedestal on a firm and level surface where fountain will remain. Place the shell on the pedestal
2. Find the pump, the 3/4" clear tubing 10" long, and the rubber stopper. Attach the piece of 3/4" clear tubing 10" long onto the outlet side of the pump.

Place the pump in the pump house located in the center of the shell and run the plug end of the electrical cord down the PVC pipe in the pump house and down through the pedestal. Retrieve cord from under pedestal and place in groove in the bottom of the pedestal. Leave enough slack in the power cord so the pump will rest on the bottom of the pumphouse. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust the position of the rubber stopper on the power cord if necessary.

3. Position the shell on the pedestal and level. To level shell, place the level on the pump house located in the center of the shell. Level in (2) Two directions left to right and front to back. Shim as needed.
4. Place padding on the side of the pumphouse located in the center of the shell.
5. Find the modern tulip finial and place on the padding in the center of the shell run the 3/4" clear tubing up thru the PVC insert in the bottom of the modern tulip finial and place it on the pumphouse of the shell. Remove the padding. Position the modern tulip centered on top of the pumphouse located in center of shell.
6. Push the 3/4" clear tubing back down until the pump is resting on the bottom on the pumphouse
7. Find the ball finial and 1/2" clear tubing 6" long. In the bottom of the ball finial there is a PVC pipe. Insert the 1/2" clear tubing into the PVC pipe about 4". **Carefully** place the ball finial in the center of the modern tulip finial by inserting the 1/2" clear tubing that is in the ball finial into the 3/4" clear tubing that is in the modern tulip.
8. Fill the shell with tap water and plug pump into a 110VAC GFCI protected outlet. Located on the front of the pump there is a dial type flow control. This will regulate water flow to the finial until the desired result is achieved.

3629sup 5/4/07