

SET UP INSTRUCTIONS 3754 - 68" TWO TIER CHARLOTTE FOUNTAIN

Open bag containing the pump kit **P40012**. In the kit you will find:

1 - 40400 (400 gallon per hour pump)

1 - rubber stopper

1 - putty tape 10" long

1 – 3/4" clear tubing 42" long

1 – hose clamp

- 1. Place pedestal on a firm and level surface where fountain will remain. Place the largest shell on the pedestal.
- 2. Find the pump, the piece of 3/4" clear tubing 42" long, the rubber stopper and the hose clamp. Place the pump in the pump house in the center of the shell and run the plug end of the power cord down the PVC pipe in the pump house and down through the pedestal. Retrieve cord from under pedestal and place in access hole in bottom of pedestal. Slip the rubber stopper onto the power cord about 15" from the pump with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Attach the piece of 3/4" clear tubing onto the outlet side of the pump with the hose clamp.
- 3. Position the largest shell on pedestal and level. To level shell, place level on the top rim of the pump house in the center of shell and level in all directions. Shim as needed.
- 4. Find the spacer. Run the 3/4" clear tubing through the center hole in spacer. Position the spacer on top of pumphouse in center of shell and level in all directions.
- 5. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of the spacer and level in all directions.
- 6. Find the finial and remove any excess concrete or tape from inside and both ends of the PVC pipe located in the center of the finial. Make sure the pump is seated on the bottom of the pump house. Before placing the finial on the fountain cut the 3/4" clear tubing 12" above the top surface of the center housing on the second shell. Slide the finial onto the 3/4" clear tubing. Position the finial on top of fountain. Find the putty tape and apply it around the 3/4" clear tubing and the PVC pipe that is in the finial to make a water tight seal.
- 7. Find the drain plugs and insert snugly into the drain inserts located in the two shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
- 8. Fill shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.

3754sup 4/9/13