

## **SET UP INSTRUCTIONS**

3745 - 56" TWO TIER CORTONA FOUNTAIN

3850 - 57" TWO TIER FLUTED FOUNTAIN W/PINEAPPLE

3854 - 49" TWO TIER MIRABELLA FOUNTAIN W/PLAIN PINEAPPLE

Open bag containing the pump kit P22503A. In the kit you will find:

1 – 40400 (400 gallon per hour pump) 1 - 27" long piece of 3/4" clear tubing 1 – tube of silicone

- 1. Place the pedestal on a firm and level surface where fountain will remain. Place the largest shell on the ground near the pedestal.
- 2. Find the pump, the 3/4" clear tubing 27" long, and the rubber stopper. Place the pump in the pumphouse located in the center of the shell and run the plug end of the electrical cord down the hole located in the pump house. Retrieve the power cord from under shell. Run the power cord down the hole that is through the pedestal. Retrieve the power cord from under pedestal and place in groove in the bottom of the pedestal. Place the largest shell on the pedestal. While placing the shell on the pedestal carefully pull the remainder of the power cord until all is hidden inside the fountain. Slip the rubber stopper onto the power cord about 10" from the pump. Insert the rubber stopper snugly into the PVC pipe. Attach the piece of 3/4" clear tubing 27" long onto the outlet side of the pump.
- 2a. This step is for the 3745 56" TWO TIER CORTONA FOUNTAIN only.

  When you retrieve the power cord from bottom pedestal, run the power cord out the square hole in bottom of the pedestal. Find the pedestal plug and position in the square hole in bottom of pedestal.
- 3. Position the large shell on the pedestal and level. To level the shell, place the level on the pumphouse located in the center of the shell. Level in (2) Two directions left to right and front to back. Shim as needed.
- 4. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position this shell centered on top of the spacer located in center of large shell. Level as stated in step #3.
- 5. Before you trim the 3/4" clear tuning to length. Push the 3/4" clear tubing back down until the pump is resting on the bottom on the pumphouse. Cut the 3/4" clear tubing 8" above the top surface of the center housing on the second shell. Find the finial. In the center of the finial you will see a PVC pipe. Insert the 3/4" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the second shell. Position the finial on the fountain.
- 6. Find the drain plug and insert snugly into the drain insert located in the large shell of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
- 7. Fill shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the built in flow control dial on the front of the pump until the desired result is achieved.

3745sup 3/4/11