

SET UP INSTRUCTIONS

3857 - 79" FOUR TIER PICASSO FOUNTAIN

Open bag containing the pump kit **P46006**. In the kit you will find:

1 - 40460 (460 gallon per hour pump) 1 – 3/4" X 1/2" plastic tee 1 - rubber stopper
1 - 60" long piece of 3/4" clear tubing 1 – 1/2" plastic tee 1 - tube of silicone
1 - 8" long piece of 1/2" kink free tubing

1. Place pedestal on a firm level surface where fountain will remain. Place the largest shell on the ground near the pedestal.
2. Find the pump and the rubber stopper. Place pump in the center of the large shell and run the plug end of the power cord down the PVC pipe located in the pump house in the center of the shell. Retrieve the power cord from under shell. Run the power cord down the hole that is through the pedestal. Retrieve cord from under pedestal and place in groove in the bottom of pedestal.
3. Place the largest shell on the pedestal. While placing the shell on the pedestal carefully pull the remainder of the power cord until all is hidden inside the fountain. Slip the rubber stopper onto the power cord about 20" from the pump. Insert the rubber stopper snugly into the PVC pipe.
4. Position the largest shell on pedestal and level. To level shell, place level on top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**
5. Find the 3/4" clear tubing 60" long attach one end to the outlet side of the pump.
6. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the large shell and level. To level shell, place level on center housing in center of shell. Level as stated in step #4.
7. Find the third shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the previous shell and level. To level shell, place level on center housing in center of shell. Level as stated in step #4.
Check to make sure that the pump is seated on the floor of the pump house in the large shell. Cut the 3/4" clear tubing 1" below the top surface of the center housing in the large shell.
8. Find the 3/4" X 1/2" plastic tee, the 1/2" plastic ell and the 1/2" kink free tubing. Attach one end of the 1/2" kink free tubing onto the middle connection of the 3/4" X 1/2" plastic tee. Attach the 1/2" plastic ell onto the opposite end of the 1/2" kink free tubing. Attach an end connection of the 3/4" X 1/2" plastic tee onto the end of the 3/4" clear tubing located in the center of the third shell. Attach the remainder of the 3/4" clear tubing onto the opposite end connection of the 3/4" X 1/2" plastic tee.
9. Find the fourth shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the previous shell and level. To level shell, place level on center housing in center of shell. Level as stated in step #4.
10. Trim the 3/4" clear tubing 6" above the top surface of the center housing of the fourth shell. Find the finial. In the center of the finial there is a PVC pipe, clean any excess concrete or tape from both ends and inside of PVC pipe. Slip the finial onto the 3/4" clear tubing and position the finial on top of fountain.
11. Find the three drain plugs and insert snugly into the drain inserts located in the three larger shells. Remove any tape and or dirt from the drain inserts before you insert the drain plugs.
12. Fill shells with water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.