

SET UP INSTRUCTIONS 3570 – TWO TIER CHESIRE FOUNTAIN ON SQUARE PEDESTAL 3635 – TWO TIER CHESIRE FOUNTAIN (no pedestal)

Open the bag containing the pump kit P16026. In the kit you will find:

1 - 40160 (160 gallon per hour pump)

1 - LED light kit (WHITE)

1 - hose clamp

1 –1/2" kink free tubing 12" long

1 – butyl tape 2" long

1 – tube of silicone

1 – 2-hole rubber stopper

- 1. Place the pedestal on a firm and level area where the fountain will remain. Place the fountain bowl on the pedestal.
- 1a. If your fountain does not have a pedestal.

Place the fountain bowl on a firm and level area where the fountain will remain.

- 2. Located inside the fountain bowl there is a PVC insert. Remove any tape and or dirt from inside the PVC insert before you insert the rubber stopper. Find the pump and the LED light and run the plug end on both power cords down the PVC insert located in the fountain bowl and down the hole in the pedestal. Leave about 12" of slack on both power cords inside the fountain bowl.
- 3. Find the 2-hole rubber stopper and the tube of silicone. Apply a dab of silicone in both holes in the rubber stopper. Slip the rubber stopper onto the power cords about 8" from the body of the pump and about 12" from the LED light head with the smaller end of the rubber stopper facing away from the pump and the LED light. Apply silicone around the inside edge of the PVC insert located in the fountain bowl and around the outside edge of the rubber stopper. Retrieve both power cords from under the pedestal or fountain bowl and place both in the groove in the bottom of the pedestal or fountain bowl. Insert the rubber stopper snugly into the PVC insert. Apply more silicone on top and around the rubber stopper and the power cords. **Don't skimp on the silicone you want a watertight seal.**
- 4. Find the piece of 1/2" kink free tubing 12" long. Attach one end of the 1/2" kink free tubing 12" long to the outlet of the pump with the hose clamp. Adjust the dial type flow control located on the front of the pump to about the 2 o'clock position. Attach the 1/2" barb fitting on the LED light to the opposite end of the 1/2" kink free tubing.
- 5. Fill the fountain bowl with about 5" of tap water. Find the spoked cover plate and Carefully place it in the fountain bowl while feeding the LED light up through the hole in the center of the spoked cover plate. Find the finial and Carefully place it on the spoked cover plate while feeding the LED light up through the hole in the center of the finial. Position the finial so the water will drip in the four open areas of the spoked cover plate.
- 6. Find the butyl tape. Roll the butyl tape back and forth between the palms of your hands until it is a round strip about 1/4" diameter and 5" long. Apply the strip of butyl tape around the LED light head. Push the LED light head down into the hole in the center of the finial and seal the hole around the LED light head with the butyl tape strip.
- 7. Connect the power cord on the LED light to the transformer. Plug the power cord of the pump and the LED light transformer into a 110VAC GFCI protected outlet. If necessary, adjust the water flow using the dial type flow control located on the front of the pump.

3570sup 4/26/18 3635sup 5/26/18